



MODEL AT44R

NODE ADDRESS SET FOR 0FH

COMMAND STRUCTURE:

- *LOC<0FH> LOCATE COMMAND, LUNIT<0FH>
- *GET<0FH> GET COMMAND, GXX=00II (00=RLY, II=TTL)
- *KXX<0FH,XXH,YYH> 0FH=ADDR,XXH=OUTPUT#,YYH=ARGUMENT
XXH=RELAY 01H-04H (FORM-C OUTPUTS), YYH=TIMER
YYH=TIMER VALUE 0.5 SECOND INCREMENTS
XXH=RELAY ALL = 0AH(PARALLEL), YYH=PATTERN
XXH=TTL 11H-10H, YYH=00H=OFF OR YYH=FFH=ON
XXH=ALLTTL = 1AH=PARALLEL, YYH=PATTERN
- *VER<0FH> VERSION COMMAND, VER=250227
- *TYP<0FH> TYPE COMMAND, TYPE=AT44R-REV-A&B
- *TMR<0FH> READ TIMERS COMMAND, TXX=0A-FF-10-00
K1=0A=WILL DEACTIVATE IN APPROX. 5 SECONDS
K2=FF=ACTIVE AND WILL REMAIN ACTIVE (FF=DN)
K3=10=WILL DEACTIVATE IN APPROX. 8 SECONDS
K4=00=IS NOT ACTIVE (00=OFF)
NOTE: FF=ACTIVE AND WILL REMAIN ACTIVE
UNTIL A LOWER VALUE OR '00' IS SENT

RE-Smith
www.rs485.com
 4311 R. E. Smith Drive, West Chester, Ohio 45069
513-874-4796

\$99.00ea. / \$79.00ea. 100 QTY.

This drawing is the property of R. E. SMITH and shall not be used except with the written permission of R. E. SMITH, no copies shall be made of it and all proprietary rights in the matter contained in this drawing are the property of R. E. SMITH. COPYRIGHT - R. E. SMITH 1997-2008		DRAWN BY RES	SUBJECT RS485 TO DIGITAL	
		DATE 2-20-08	FOR 4-INPUTS/4-RELAYS	
SHEET 1 OF 1		SCALE NONE	RES R. E. SMITH 4311 R. E. SMITH DRIVE WEST CHESTER, OHIO 45069	
AT44R		CHKD. BY RES	DWG. NO. AT44R	REV. B