

Phone: 513-874-4796 Fax: 513-874-1236

PRELIMINARY INFORMATION

**PF1616L OPERATION GUIDE
PF1616L RS485/RS232/USB/ETHERNET/
900Mhz RF/Fiber Optic REMOTE IO BOARD
(Software Version 1.3A, February 1, 2004)**

INTRODUCTION

The PF1616L Remote Relay Board has 16 Opto-Isolated Inputs and 16 relay outputs. The unit can be controlled by our simple/efficient command structure from a host computer (computer mode), such as a PC with standard firmware. Two units can be connected in a standalone mode passing inputs to outputs on the adjacent unit. The unit can communicate using RS485 or RS232, at data rates up to 115.2K bits/second, with optional communication modules the unit can work on Ethernet, Fiber Optic, Universal Serial Bus (USB1.1 and USB2.0) or 900 Mhz RF. The PF-series devices have a unique feature being field upgraded to new or custom versions of firmware while installed in a network.

The PF1616L has an onboard switching regulators for 9-35VDC (7.5W) operation, LED indicators monitor data flow of the serial port and relay status. 22 jumpers for communications address, Baud rate, mode control, etc.




Figure 1. PF1616L

PRELIMINARY COMMAND STRUCTURE FOR
THE PF1616L UNIT AND OTHER PFxxxxx I/O BOARDS
(UPDATED 2-01-04)

COMMAND	RESPONSE (X=NIBBLE)	NOTES
*LOC(0FH) LUNIT(0FH)-XXXX#<CR><LF>	XXXX=FLAGS	
The LOCate command returns any flags which might be defined, currently the PF1616L has no defined flags. This command is useful to scan a network to determine units present.		
*GET(0FH) GUNIT(0FH)-XXXX-IIII-OOOO-JJJJ#<CR><LF>	X=FLAGS I=INPUTS O=OUTPUTS J=JUMPERS	
The GET command returns the status of the unit, flags, inputs, outputs and jumpers are encoded and returned.		
*VER(0FH) VER-1.3A-20040201<CR><LF>		
The VERsion command returns the version and date code of the software.		
*TYP(0FH) TYPE-PFAHUB-REV-A<CR><LF>		
The TYPe command returns the unit type and hardware revision code.		
*HLP(0FH) DISPLAY HELP PAGE<CR><LF>		
The HeLP command displays the help page.		
----- I/O BOARD COMMANDS -----		
*KXX(ADDRESS, MASK/RELAY, PARAMETER)		
The KXX command is useful to control the relay outputs, this command has two main forms. The mask mode which allows control of multiple relays and the individual mode which allows individual control over a relay.		
When the MASK/RELAY value is AAH, AA00H, 0AA0H, or AAAAH multiple control is selected. When the MASK/RELAY value is a number 01H - 10H individual relay control is selected. Some examples follow.		
*KXX(0FH,AAAAH,XXXXH)	KALL-XXXX<CR><LF>	XXXX=BIT PATTERN (HEX)
(ADDRESS, ALL RELAYS, MASK VALUE)		NOTE: TERMINATES ALL TIMERS

PF1616-Multiple simultaneous relay control

*KXX command to control multiple ON/OFF relay control simultaneously choices are:

1. To control all 16 relays ON/OFF state use the command - *KXX(addrH, AAAAH, ON/OFF-maskH[16bit mask])
2. To control upper 8 relays ON/OFF state use the command - *KXX(addrH, AA00H, ON/OFF-maskH[8bit mask])
3. To control lower 8 relays ON/OFF state use the command - *KXX(addrH, AAH, ON/OFF-maskH[8bit mask])
4. To control middle 8 relays ON/OFF state use the command - *KXX(addrH, AA0H, ON/OFF-maskH[8bit mask])

Examples (address = 0FH)

HI 5's would be - *KXX(0FH,AA00H,55H)KALL-5500

Result: K9-ON K10-OFF K11-ON K12-OFF K13-ON K14-OFF K15-ON K16-OFF

LO 5's would be - *KXX(0FH,AAH,55H)KALL-0055

Result: K1-ON K2-OFF K3-ON K4-OFF K5-ON K6-OFF K7-ON K8-OFF

MID 5's would be - *KXX(0FH,AA0H,55H)KALL-0550

Result: K4-ON K5-OFF K6-ON K7-OFF K8-ON K9-OFF K10-ON K11-OFF

ALL 0's would be - *KXX(0FH,AAAAH,0000H)KALL-0000

Result: K9-OFF K10-OFF K11-OFF K12-OFF K13-OFF K14-OFF K15-OFF K16-OFF
K1-OFF K2-OFF K3-OFF K4-OFF K5-OFF K6-OFF K7-OFF K8-OFF

ALL A's would be - *KXX(0FH,AAAAH,AAAAH)KALL-AAAA

Result: K9-OFF K10-ON K11-OFF K12-ON K13-OFF K14-ON K15-OFF K16-ON
K1-OFF K2-ON K3-OFF K4-ON K5-OFF K6-ON K7-OFF K8-ON

PF1616-Individual relay control

To control individual relays, the relay number is specified as the second parameter to the *KXX command and a time value is specified as the third parameter. If the time value is FFFFH the relay will be activated and remain activated until commanded otherwise. Any other value greater than zero specifies a time in .1S increments the relay should remain activated and then deactivate after the timeout automatically. Specifying a value of 0000H for the time value will deactivate the relay if active.

*KXX(0FH,01H,XXXXH) K01-DDDD<CR><LF>	DDDD=XXXX=TIME (HEX) 0.1SEC.
(ADDRESS, RELAY#, TIMER)	0000H=OFF, FFFFH=ON

*KXX(0FH,01H,XXXH) K01-0DDD<CR><LF>	"	"
-------------------------------------	---	---

*KXX(0FH,01H,XXH) K01-00DD<CR><LF>	"	"
------------------------------------	---	---

*KXX(0FH,01H,XH) K01-000D<CR><LF>	"	"
-----------------------------------	---	---

OPTION COMMANDS

***OPT(0FH,MSRTXDLY=50)** - This command sets the standalone master retransmit delay if the slave does not respond. The increments are in .1 seconds.

***OPT(0FH,MSRDO=50)** - This command sets the standalone Relay Drop Out time. The increments are in .1 seconds. A value of 0 specifies no drop mode is enabled.

***OPT(0FH,READ)** - This command reads the internal non-volatile option settings. The following output represents the boards response to this command:

```
OPTIONS(0FH,  
TRANSMIT DELAY=32H (*500uS)  
EVENT MODE=N  
INPUT DEBOUNCE=10 mS  
AUTO SEND TIME=0 S  
MASTER RETRY TX DELAY=50 *.1S  
MASTER/SLAVE RELAY DROP OUT DISABLED  
Internal 12-Bit Address = 022H  
Address Mode 8Bit External (J27-J34) [ACTIVE]
```

TIMER READING

***TMR(0FH)TIMERS(0FH)** -

```
1:0000    9:0000  
2:0000   10:0000  
3:0000   11:0000  
4:0000   12:0000  
5:0000   13:0000  
6:0000   14:0000  
7:0000   15:0000  
8:0000   16:0000
```

EVENT MODE COMMANDS

```
*OPT(0FH,TDLY=05H)OPTIONS(0FH,TRANSMIT DELAY=05H)  
*OPT(0FH,EVNT=N)OPTIONS(0FH,EVENT MODE=N)  
*OPT(0FH,EVNT=Y)OPTIONS(0FH,EVENT MODE=Y)  
*OPT(0FH,DBNC=200)OPTIONS(0FH,INPUT DEBOUNCE=200 milli-seconds)  
*OPT(0FH,AUTO=0)OPTIONS(0FH,AUTO SEND TIME=0 Seconds)  
*OPT(0FH,AUTO=5)OPTIONS(0FH,AUTO SEND TIME=5 Seconds)
```

NOTES:

TDLY=XXH, XX must be hex digits, 00,01,02,... 2 digits. 255 decimal max.
ADDR=XXH, Specify the internal address, default 0E hex.

BOARD ADDRESS COMMANDS

```
*OPT(0FH,IAS)OPTIONS(22H, 8-BIT INTERNAL ADDRESS)  -- Board internal  
address 8 bits  
*OPT(0FH,IAL)OPTIONS(022H, 12-BIT INTERNAL ADDRESS) -- Board internal  
address 12 bits
```

OPTION COMMANDS (continued)

*OPT(0FH, TDLY, 01H) -- OPTIONS(0FH,TDLY=01H)

Set the transmit delay increments of 250us per increment.

*OPT(0FH, I2CA, 01H) -- OPTIONS(0FH,I2CA=01H)

Set the base address of the I2C Display

Master/Slave Mode Description - Format 1

<M/S><Format><Flags><->*<Addr(2)><,><In-data><,><Out-data><*><Checksum(4)><CRLF(2)>

- <M/S>** Master/Slave tag. Tags the data so the display board knows where to put it.
- <Format>** Single character 0 to F. Allows for future data formats as they are dreamed up.
0=AT2424SAL Format <not supported in the PF1616L>
1=PF1616L Format

The balance of the packet depends upon the format defined by the **Format** byte above.

Format 1 Description:

Typical master transmission M10-0F,0001,0001*FCAC<cr><lf>

- <Flags>** Single character 0 to F to define 4 flag bits.
- | Bit | Definition |
|-----|--|
| 3 | Previous received packet error status. |
| 2 | Timeout Error. No response from slave |
| 1 | Reserved |
| 0 | Reserved |
- <->** Dash. Start of data field marker
- <Addr(2)>** Ascii Hex Data nibbles describing 8 bits of address data.
- <,>** Comma separating address and Input data
- <In-data>** Input data field. 2 to n Ascii Hex Data nibbles describing 8 to 24 bits or more of the sending units input status.
- <,>** Comma separating input data and output data.
- <Out-data>** Output data field. 2 to n Ascii Hex Data nibbles describing 8 to 24 bits or more of the sending units output status.
- <*>** Asterisk. End of data field marker.
- <Checksum(4)>** 16 bit two's complement of all characters up to, and including, the end of data field marker.
- <CRLF(2)>** Two characters, D(hex) and A(hex)

Configuration Tables

Notes and abbreviations:

I = Install jumper (JX), **R** = Remove Jumper (JX), **XX** = don't care,
M/S = Master or Slave Mode, **M** = Master Mode, **S** = Slave Mode,
TX = Transmit, **RX** = Receive, * = Factory Default Setting,
HW = Hardware Setup.

Table 1: RS232/RS485 Configuration

JX	MODE	JUMPER FUNCTION AND NOTES				
J1-4	HW	J1	J2	J3	J4	RS-232 Port Configuration
		I*	I*	R	R	Computer Mode
		R	R	I	I	Modem Mode
J5	HW					
J6	HW					
J14	SW	Standalone mode enabled if removed, computer mode if installed (default).				
J15	SW	Standalone mode unit selection master=installed, slave=removed.				
J16	SW	Dual parser enabled if removed, helpful to reload firmware or configuration. If removed the unit will respond to computer mode commands while standalone mode is paused by isolating one of the units.				
J17	SW	Internal/External Address Enable, External J27-J34 if installed, Internal 8bit or 12bit configurable with option command if removed.				
J18-J21	SW	Baud Rate Selection Jumpers See Table 2.				
J27-J34	SW	External Address (J27-msb : J34-lsb)				

Table 2: RS-232 BAUD RATE SETUP**Baud Rate Selection in any MODE (J18 – J21)****Note: Sampled on power-up only!**

HEX	J18	J19	J20	J21	Baud
F	I*	I*	I*	I*	9600
E	I	I	I	R	115.2K
D	I	I	R	I	9600
C	I	I	R	R	57.6K
B	I	R	I	I	38.4K
A	I	R	I	R	28.8K
9	I	R	R	I	19.2K
8	I	R	R	R	14.4K
7	R	I	I	I	9600
6	R	I	I	R	4800
5	R	I	R	I	2400
4	R	I	R	R	9600
3	R	R	I	I	9600
2	R	R	I	R	9600
1	R	R	R	I	9600
0	R	R	R	R	9600

Table 6: TABLE OF SPECIFICATIONS FOR COMMON COMMUNICATIONS STANDARDS:

SPECIFICATIONS		RS232	RS423	RS422	RS485
Mode of Operation		SINGLE-ENDED	SINGLE-ENDED	DIFFERENTIAL	DIFFERENTIAL
Total Number of Drivers and Receivers on One Line		1 DRIVER 1 RECVR	1 DRIVER 1 RECVR	10 DRIVER 10 RECVR	32 DRIVER 32 RECVR
Maximum Cable Length		50 FT.	4000 FT.	4000 FT.	4000 FT.
Maximum Data Rate		20kb/s	100kb/s	10Mb/s	10Mb/s
Maximum Driver Output Voltage		±25V	±6V	-0.25V to +6V	-7V to +12V
Driver Output Signal Level (Loaded Min.), (Unloaded Max.)	Loaded	±5V to ±15V	±3.6V	±2.0V	±1.5V
	Unloaded	±25V	±6V	+/-6V	±6V
Driver Load Impedance (Ohms)		3k to 7k	>=450	100	54
Max. Driver Output Current in High Impedance State	Power On	N/A	N/A	N/A	±100uA
	Power Off	±6mA @ ±2v	±100uA	±100uA	±100uA
Slew Rate (Max.)		30V/uS	Adjustable	N/A	N/A
Receiver Input Voltage Range		±15V	±12V	-10V to +10V	-7V to +12V
Receiver Input Sensitivity		±3V	±200mV	±200mV	±200mV
Receiver Input Resistance (Ohms)		3k to 7k	4k min.	4k min.	>=12k